

Hochlastzeitfenster 2018

Stand: 26.10.2017

	Frühling	Sommer	Herbst	Winter
Mittelspannung	09:00 - 13:45	10:45 - 13:45	-----	10:45 - 11:30
Umspannung MS/NS	-----	17:45 - 22:30	17:45 - 21:30	-----
Niederspannung	-----	-----	-----	18:00 - 20:00

